

Qware Controller



QW WII1071

- 8 way cross button
- Action button and trigger
- Full motion control
- Integrated speaker and vibration
- LED indication for player indication
- For use with and without motion plus
- Including wrist wrap
- Need 2 AA-batteries (not included)
- Compatible with all Qware Wii rechargeble batteries and chargers



Article code	QW WII1071BL
EAN code	8716502021857
Article code	QW WII1071BU
EAN code	8716502021864
Article code	QW WII1071PK
EAN code	8716502021888
Article code	QW WII1071RD
EAN code	8716502021871
Article code	QW WII1071WH
EAN code	8716502021840

Colours available:



Gaming to the max...